# **WARNING**

Be sure to read this user's manual thoroughly before use, and follow the instructions that it contains. This is critical for your safety, and will also prevent premature product failure due to incorrect use or installation.

#### **BOX CONTENTS**

The box contains a Handlebar.

### **TOOLS REQUIRED**

See your stem manual.

#### IMPORTANT SAFETY INFORMATION

Check the torque values after first 30 to 90 km or 1 to 3 hours of use. If necessary tighten them as prescribed with a torque wrench. Check at least every 500km or 25 hours of use thereafter.

Products are not guaranteed against natural wear and deterioration from normal use and aging. The maximum total weight all loaded (rider + clothing + protective gear + backpack, luggage etc.) is 100 kg.

## **INSTALLATION**

Before you start instalation check that your stem have 31,8 clamp diameter. Check that the handlebar is clean and free from any oil or grease.

Tighten torques: Stem - 6Nm Max Shifters and brake levers – 4Nm Max